



customer service

if there are any missing parts or you have any questions regarding assembly, please call our customer service line on 1300 94 20 50

care and cleaning

do not scratch or chip the finish. do not use abrasive chemicals for cleaning. clean with mild soap on a soft rag. rinse and dry thoroughly


important safety information

- do not use if parts are missing and do not substitute parts, contact incy interiors for replacement parts
- this item must be fixed to the wall with the safety bracket provided to prevent it from tipping over if a child climbs or hangs onto it.

assembly instructions

it is advised to have two adults to complete the assembly of the bookcase

1. stand sides upright approximately 1m apart, with holes facing inwards
2. insert top front of bookcase and bottom into holes on sides, secure with screws as provided
3. attach top of dresser and secure with screws provided
4. Screw in feet to bottom of dresser
5. insert plugs where you would like shelves
6. place shelf on top of plug



A kit has been included to allow you to attach the bookcase to the wall. Simply attach the bracket to the bookcase and screw the bracket into the wall to secure using a fixing device that is suitable for the material the wall is made from.

manufacturer details

Incy Interiors
2a Piper St
Bathurst NSW 2795
1300 94 20 50